Option 1

Battery 1
2s LiPo
4000 mAh

Battery 2
2s LiPo
4000 mAh

Fromco
Wolverine
Switch
2 In - 2 out leads

9 Channel Rx	
Channel 1	Right wing HV servo
Channel 2	Left wing HV servo
Channel 3	elevator right, HV servo
Channel 4	elevator left, HV servo
Channel 5	rudder 1, HV servo
Channel 6	Throttle servo, HV servo
Channel 7	IBEC, switch to turn on /off
Channel 8	Switch plug in 1
Channel 9	Switch plug in 2

Tech-Aero IBEC set to 6 volts

Ignition



Option 2

Battery 1
2s LiPo
4000 mAh

Battery 2
2s LiPo
4000 mAh

Fromco
Wolverine
Switch
2 In - 2 out leads

6-7 Channel Rx 1	
Channel 1	Right wing HV servo
Channel 2	elevator right, HV servo
Channel 3	
Channel 4	rudder 1, HV servo
Channel 5	
Channel 6	Switch plug in 1
Channel 7	

6-7 Channel Rx 2	
Channel 1	Left wing HV servo
Channel 2	elevator left, HV servo
Channel 3	Throttle servo, HV servo
Channel 4	
Channel 5	IBEC, switch to turn on /off
Channel 6	Switch plug in 2
Channel 7	