Option 1

14 Channel Rx	
Channel 1	right wing outter, HV servo
Channel 2	right wing inner, HV servo
Channel 3	left wing outter, HV servo
Channel 4	left wing inner, HV servo
Channel 5	elevator right, HV servo
Channel 6	elevator left, HV servo
Channel 7	rudder 1, HV servo
Channel 8	rudder 2 (optional), HV servo
Channel 9	Throttle servo, HV servo
Channel 10	IBEC, switch to turn on /off
Channel 11	Switch plug in 1
Channel 12	Switch plug in 2
Channel 13	open
Channel 14	open

Battery 1
2s LiPo
4000 mAh

Battery 2
2s LiPo
4000 mAh

Fromco
Wolverine
Switch
2 In - 2 out leads



Tech-Aero IBEC set to 6 volts

Ignition

Option 2

7 Channel Rx 1	
Channel 1	right wing outter, HV servo
Channel 2	left wing outter, HV servo
Channel 3	elevator right, HV servo
Channel 4	rudder 1, HV servo
Channel 5	Throttle servo, HV servo
Channel 6	open
Channel 7	Switch plug in 1

7 Channel Rx 2	
Channel 1	right wing inner, HV servo
Channel 2	left wing inner, HV servo
Channel 3	elevator left, HV servo
Channel 4	rudder 2 (optional), HV servo
Channel 5	open
Channel 6	IBEC, switch to turn on /off
Channel 7	Switch plug in 2

Battery 1
2s LiPo
4000 mAh

Battery 2
2s LiPo
4000 mAh

Fromco
Wolverine
Switch
2 In - 2 out leads